

6 Replacement Spares

Refer to Chapter 6 for a full list of replacement spares.

7 Wiring Diagrams

Refer to Ship's Manual 65800010B Chapter 3 for complete system installation diagrams.

The wiring diagrams Included in this section are as follows:

Figure 1.34 S-Band Turning Unit Schematic

Figure 1.35 S-Band Bulkhead Transceiver Schematic.

Intentionally Blank




Figure 1-34 S-Band Turning Unit Schematic

Chapter 1

S-Band Scanner Units and Transceivers

A3 page 1-75/76 Figure 1.34, discard this A4 sheet.




Figure 1.35 S-Band Bulkhead Transceiver Schematic

Chapter 1

S-Band Scanner Units and Transceivers

A3 page 1-77/78 Figure 1.35, discard this A4 sheet.