

CHAPTER 6

SPARES LISTING

Contents

6.1	INTRODUCTION	3
6.2	REPAIR STATUS	3
6.3	SPARES LIST.....	4

INTENTIONALLY BLANK

6.1 INTRODUCTION

Servicing is by modular replacement. The table on the following page lists the spare parts required to support this servicing policy.

The list indicates the repair status for each part, and the approximate time to replace the part once the fault has been diagnosed.

Procedures for replacing the parts are contained in the manuals listed.

6.2 REPAIR STATUS

OB Indicates that a repair can be made on board.

D Indicates that a part is non repairable and should be disposed of.

C Contains hazardous material.

6.3 SPARES LIST

Designation	Part Number	N.S.N. where available	Repair Status	MTTR Hrs	Hazardous material indicator	Manual Reference
Video Control Unit Logic PCB Assy	T65857801		D	0.5		Chapter 4
TCU PSU PCB Assy	T65841803		D	0.5		Chapter 4
Video Control Panel Assy	T65857600		D	0.25		Chapter 4
Fuse 3.1A	MA00007245		D	0.25		
Mains Input Filter	1586513		D	0.5		
Coaxial Cable Assy	MA00013797		D	0.5		
20 Way Ribbon Cable Assy	65841501		D	0.25		
Ribbon Cable VCU Control Panel	65857501		D	0.25		
Cable Assy AC Mains	65841503		D	0.5		
Cable Assy Filter Cover	65841502		D	0.5		

Notes:

- 1 Repair status:
OB = On board
D = Disposable non-repairable
C = Contains hazardous material
- 2 MTTR does not include diagnostic time.