

Nº	Toshiba PN	Description
1A	P000261430	PCB FE2SY2
1B	P000261440	PCB FE2LP2
1C	P000261450	PCB FE2LK2
2	P000261460	PCB FE2CP2
3	P000258790	PCB FE2MU2
4	P000262020	DUMMY DAA PCB
11	P000257530	COLOR LCD MODULE
11A	P000261110	FL TUBE
11B	P000261120	TAPE
11C	P000261130	SCREW
11D	P000261140	SCREW M2X2
11E	P000246170	FILAMENT TAPE
11F	P000246180	POLYIMIDE TAPE
13	P000257540	FL INVERTER
14	P000257600	KEYBOARD UNIT
15	P000258800	HDD UNIT (4.3GB)
15-1	P000262190	HDD UNIT (4.3GB)
15-2	P000282650	HDD UNIT (4.3GB)
16	PA2505UR	BATTERY PACK
17	P000258810	FDD 3.5 INCH
17-1	P000265450	FDD 3.5 INCH
17A	P000258840	FDD COVER, UPPER
17B	P000258850	FDD COVER, LOWER
17C	P000221830	FDD CONNECTOR
17D	P000258860	FDD SHIELD
17E	P000221850	FDD INSULATOR
17F	P000258870	FDD EJECT BUTTON
17G	P000258880	FDD LABEL
17G-1	P000266190	FDD LABEL
18	P000258890	FDD CABLE
19	PA2450U	UNIVERSAL AC ADAPTER
20	P000182200	AC CORD SET
21	P000258900	NI-MH BATTERY
22	P000258960	SPEAKER
23	P000258910	CARDBUS SLOT
24	P000258920	MEMBRANE SWITCH
25	P000257680	STICK CAP SET
26	P000220300	MODULAR CABLE
27	P000258950	I/O ADAPTOR
27-1	P000268150	I/O ADAPTOR
27-2	P000272260	I/O ADAPTOR
27A	P000261580	ADAPTER COVER, UPPER
27B	P000261590	ADAPTER COVER, LOWER
27B-A	P000272040	ADAPTER COVER, LOWER
27C	P000261600	SHELL
27D	P000261610	I/O PCB
27E	P000261620	50P CABLE
27F	P000262200	SCREW M2.5X4N
27G	P000262210	SCREW M2.5X5N
27H	P000262220	SCREW M3X12BN
27I	P000268160	I/O ADAPTER LABEL
27I-A	P000272390	ID LABEL
28	P000258930	DC JACK HARNESS
29	P000258940	MODULAR JACK HARNESS
35	P000258820	BASE ASSEMBLY
35A	P000258970	BATTERY LATCH
35B	P000258980	BOTTOM CUSHION
35C	P000258990	MEMORY EARTH SPRING
35D	P000259000	PCB EARTH SPRING
35E	P000259010	MEMORY COVER ASSEMBLY
35F	P000259020	BATTERY LATCH SPRING
35H	P000259040	POWER SWITCH
35I	P000259050	INSULATOR, RTC BATTERY
35J	P000259060	USB COVER ASSEMBLY
35K	P000261960	POWER SWITCH LOCK
35L	P000262230	SWITCH LOCK HOLDER
40	P000258830	COVER ASSEMBLY
40A	P000259070	INVERTER HARNESS
40B	P000259080	LCD HARNESS
40C	P000259090	LED HARNESS
40D	P000259100	COVER
40E	P000261470	LCD COVER ASSEMBLY
40EE	P000259110	LCD LATCH
40EF	P000259120	LCD LATCH HOLDER
40EG	P000259130	LCD HOOK
40EH	P000233860	PUSH SPRING
40I	P000259140	LCD HARNESS GUIDE
40J	P000259150	HINGE COVER, LEFT
40K	P000259160	HINGE COVER, RIGHT
40L	P000259170	HINGE CAP, LEFT
40M	P000259180	HINGE CAP, RIGHT
40N	P000202280	EARTH SPRING
40O	P000259190	COVER STUD
40P	P000259200	BRAKE HINGE, LEFT
40Q	P000259210	BRAKE HINGE, RIGHT
40R	P000259220	INSULATOR, BATTERY CONNECT
40S	P000259230	INSULATOR, COVER
40T	P000223550	EMI GASKET
40U	P000259240	COVER, USB CUSHION
40V	P000261970	INSULATOR, HINGE RGB
42	P000261480	LCD MASK ASSEMBLY
42-1	P000283320	LCD MASK ASSEMBLY
42A	P000259260	LCD CUSHION
42B (N/S)	P000297060	INSULATOR, INV. SPACER
43	P000259270	I/O COVER ASSEMBLY
44	P000259280	SHUTTER ASSEMBLY
45	P000259290	EJECTOR ASSEMBLY
46	P000259300	HDD BRACKET ASSEMBLY
47	P000259310	HDD COVER
48	P000259320	KEYBOARD HOLDER
49	P000259330	ISP SWITCH BUTTON
50	P000259340	SOUND JACK COVER
51	P000259350	DAA COVER WW
52	P000259360	KEYBOARD SUPPORT
53	P000259370	DUMMY CARD

54	P000259380	SPEAKER HOLDER
55	P000259390	FAN COVER
56	P000259400	SHIELD, GENERATOR
57	P000261490	EARTH, BATTERY CONNECTOR
58	P000261500	CPU GROUND SEAL
59	P000259410	LCD MASK SEAL
60	P000261510	DOCKING CONNECTOR
62	P000274750	LCD INVERTER PLATE
63	P000275180	EARTH PLATE CAUTION LABEL
OPTIONS		
OP	KTT8000/32	32MB SDRAM MEMORY
OP	KTT8000/64	64MB SDRAM MEMORY
OP	KTT8000/128	128MB SDRAM MEMORY
OP3	PA2450U	UNIVERSAL AC ADAPTER
OP4	PA2505UR	BATTERY PACK
OP5	PA2506UR	HIGH CAPACITY BATTERY PK
OP6	PA2508U	BATTERY CHARGER
OP7	PA2722U	10/100 NETWORK/DVD DOCK
OP8	PA2723U	10/100 NETWORK/CD DOCK