



REMOVAL AND INSTALLATION

NOTE

- When removing and installing the rear bumper, an assistant is necessary.
- Take care not to damage the front bumper and body.
- Put on gloves to protect your hands.

1. Remove the following items:
 - A. Rear transverse trim (see page BD- 5).
 - B. Luggage side trim mounting clip (see page BD- 5).
 - C. Rear combination lamp (A).
2. Remove the rear bumper cover (B) and rail (C).
3. Installation is the reverse of removal.

Fastener Locations



