


COMPONENTS



Circuit connection

Connector No.	Terminal No.	Description	Connector No.	Terminal No.	Description
M01-2	1	Head lamp passing	M01-1	1	Wiper high speed
	2	Head lamp high beam power		2	Wiper low speed
	3	-		3	Wiper parking
	4	-		4	Mist switch
	5	-		5	Wiper & washer ground
	6	-		6	Intermittent wiper
	7	Turn signal RH lamp		7	Front washer switch
	8	Flasher unit power		8	-
	9	Turn signal LH lamp		9	Rear wiper & washer
	10	Head lamp low beam power		10	Rear wiper
	11	Dimmer & passing ground		11	Intermittent rear wiper
	12	Front fog lamp switch		12	Rear wiper ground
	13	Front fog lamp switch ground		13	Intermittent wiper volume
	14	Tail lamp switch		14	Intermittent wiper ground
	15	Head lamp switch	M01-4	1	Remote control power
	16	Auto light switch		2	Cruise signal
	17	Lighting switch ground		3	Cruise ground
	18	-		4	Horn relay
I56	1	Driver initiator (low)			
	2	Driver initiator (high)			
	3	SMART driver initiator (low)			
	4	SMART driver initiator (high)			

	3	SMART driver initiator (low)
	4	SMART driver initiator (high)