2004 > G 2.0 DOHC > Brake System





Component Locating Index

BRAKE BOOSTER

Brake booster test, page BR-23 Brake booster

Replacement, page BR-24

FRONT BRAKES

Front brake Replacement, page BR-27 Front brake

Inspection, page BR-30

MASTER CYLINDER

Master cylinder Replacement, page BR-20 Master cylinder Inspection, page BR-21

BRAKE PEDAL

Brake pedal and brake switch Adjustment, page BR-9

PARKING BRAKE

Parking brake switch Inspection, page BR-14

Parking brake check and adjustment, page BR-11

REAR BRAKES REAR DISC BRAKE: Rear brake

Replacement, page BR-33 Rear brake Inspection, page BR-36

REAR DRUM BRAKE:

Rear drum brake Inspection, page BR-38 Rear brake shoes Replacement, page BR-39 Rear wheel cylinder Replacement, page BR-41

BRAKE HOSES/LINES

Brake hoses and lines Inspection, page BR-17 Brake hoses Replacement, page BR-17 Brake system bleeding, page BR-12

Component Locating Index

BRAKE BOOSTER

Brake booster test, page BR-23 Brake booster Replacement, page BR-24

PARKING BRAKE

Parking brake check and adjustment, page BR-11 Parking brake switch Inspection, page BR-14

FRONT BRAKES

Front brake Replacement, page BR-27 Front brake





Rear brake Replacement, page BR-33 Rear brake

Inspection, page BR-36

REAR DRUM BRAKE: Rear drum brake

Inspection, page BR-38 Rear brake shoes

Replacement, page BR-39 Rear wheel cylinder

Replacement, page BR-41

MASTER CYLINDER

Master cylinder Replacement, page BR-20 Master cylinder Inspection, page BR-21

BRAKE PEDAL

Brake pedal and brake switch Adjustment, page BR-9

BRAKE HOSES/LINES

Brake hoses and lines Inspection, page BR-17 Brake hoses Replacement, page BR-17 Brake system bleeding, page BR-12