




INSPECTION (AUTO A/C)



Check the resistance between terminals 1 and 2 of thermistor connector at each temperature.