





CONNECTOR

MANUAL A/C



AUTO A/C



THERMO AMP EXTERNAL CIRCUIT DIAGRAM OF THERMO AMP (MANUAL A/C)

