











SPECIAL TOOLS

Tool (Number and name)	Illustration	Use
0957A-34100A Deployment tool		Airbag deployment tool PAB : 0957A-38100 DAB, BPT : 0957A-2D200 SAB : 0957A-3F100
0957A-38200 Dummy		Simulator to check the resistance of each wiring harness Dummy adapter PAB : 0957A-2D100 DAB, BPT : 0957A-1C000 SAB : 0957A-3F000
0957A-2D200 Deployment adapter		Use with deployment tool.
0957A-38500 Deployment adapter		Use with deployment tool.
0957A-3F100 Deployment adapter		Use with deployment tool.
0957A-2D100 Dummy adapter		Use with dummy.

0957A-1C000 Dummy adapter		Use with dummy.
0957A-3F000 Dummy adapter		Use with dummy.

- * DAB :Driver Airbag
- * PAB : Prassenger Airbag
- * SAB : Side Airbag
- * BPT : Belt Pretensioner