## COMPONENTS


ETACS module
Passenger compartment junction block
• No.15 fuse (15A)
Door lock control module
Front door lock actuator & switch
Central door lock/unlock relay
Rear door lock actuator & switch
Driver door key unlock switch
Door lock knob
Front door lock actuator & switch
Tailgate lock actuator & switch (5 doors)
Door lock switch
Rear door lock actuator & switch